



ISO 9001 CERTIFIED COMPANY

PRODUCT DATA SHEET

Radiator Stop Leak

Part #: 31199

325 mL

Rislone® Radiator Stop Leak

Rislone® Cooling System Radiator Stop Leak seals internal, external and coolant-to-oil leaks. Works safely and effectively on plastic, aluminum and metal radiators, heater cores, blocks, heads, gaskets, and freeze plugs. Compatible with both conventional silicate-based and extended life (OAT/HOAT) antifreeze, all types, and colors. Can also be used in straight water.

Protects the Entire Cooling System

Stops Current and Future Leaks

Lubricates Water Pump Seal

Helps Control Electrolysis

Use on Cars, Trucks, Vans, SUVs, & RVs

DANGER: Opening the cooling system while the engine is hot or running may cause severe burns.

NOTE: Cooling systems that are dirty or partially clogged should be flushed before use.

INSTRUCTIONS:

Pour Radiator Stop Leak into a cool radiator. If direct access to radiator is not available, install in overflow tank. One bottle treats up to 15 litres. Use 1/2 bottle for 4-cylinder engines. Fill radiator and overflow tank to proper level and reinstall cap. Drive/idle engine for 15 to 30 minutes. If leak continues, second application may be required or mechanical attention is needed. Leave Rislone Radiator Stop Leak in cooling system for continued protection.

DOSAGE:

Use one bottle for 6-, 8-, and 10-cylinder gas or diesel engines.

3-, 4-, and 5-cylinder engines, use 1/2 bottle.

One bottle treats systems up to 15 litres.

For larger systems use one bottle for every 12 litres of cooling system capacity.

