



ISO 9001 CERTIFIED COMPANY

Jack Oil with Stop Leak

Part #: 32012

370 mL

Jack Oil with Stop Leak

Rislone® Jack Oil with Stop Leak is specially designed to stop seal and o-ring leaks caused by normal jack wear and age. If you are having to add oil to your jack, it has a leak. Easy fill cap is great for topping fluid off.

Brings life back to old jacks and prevents leaks & seepage on newer jacks. Premium formulation reconditions seals to stop current and prevent future leaks.

WORKS ON ALL:

Bottle Jacks
Floor Jacks
Lifts & Rams
Shocks
Snow Plows

World's Most Trusted Stop Leak Brand Since 1921

Mixes All Approved Hydraulic Jack Oils

Safe and Easy to Use

Contains Anti-Wear & Oil Stabilizer

Non-Corrosive, Non-Clogging & Non-Foaming

INSTRUCTIONS:

Clean area around filler cap. Fill jack to proper level. Do not overfill. Cycle jack by lifting and releasing a few times to release any air caught in system. Leaks usually stop in a few days of normal use. If leak continues, repair may be required.

DOSAGE:

One bottle treats 1.5 to 2.5 litres of oil. For larger systems use one bottle for every 2 litres of oil capacity.

CAUTION:

Do not use in hydraulic brake systems.



Small Oil Leaks – Need to Add Oil 1 X per Month	✓
Medium Oil Leaks – Need to Add Oil 1 X per Week	✓
Extends System Life	✓
Preventative Maintenance	✓
Reduces Wear	✓
Inhibits Foam	✓
Corrosion Protection	✓
Floor & Bottle Jacks	✓